



NOTES:

- 1/ CHOOSE A COOL DRY MOUNTING POSITION AWAY FROM OTHER HEAT SOURCES.
- 1/ ALLOW AT LEAST 30mm AIR SPACE AROUND AMP1
- 2/ MOUNT AMP1 NARROW END ON A METAL PLATESURFACE USING ALL 4 SCREW HOLES.
- 3/ ADJUST VOLUME WITH VR1

AMP1 BLOCK DIAGRAM

DRAWING # AMP1BDa.SCH

03/08/09