



To unlock DVR control buttons-
(L is displayed in bottom L/H corner of monitor screen)

1/ Press REC button 5 times (L disappears on screen)




You are now able to press buttons.

2/ To replay press PLAY button.

3/ To Setup DVR select MENU button



Setup for number of camera channels used



Set to real time and not daylight saving